HOW SHOULD I STORE SMALL CYLINDERS?

- NEVER store or place a propane cylinder indoors or in an enclosed area such as a basement, garage, shed, or tent.
- NEVER store or place a propane cylinder in an area of excessive heat (120 degrees or higher) or near a stove, fireplace, or other heat source. The heat builds up pressure inside the cylinder, which may cause the pressure relief valve to release propane. Flash fires or explosions can result from exposing cylinders to heat.



- NEVER store or place a spare cylinder under or near a barbecue grill.
- DO NOT smoke or have any ignition sources such as flames or spark-producing electrical tools in the area while handling or transporting cylinders.

HOW SHOULD I TRANSPORT SMALL CYLINDERS?

- ALWAYS transport and store a cylinder in a secure and upright position so it will not fall, shift, or roll.
- ALWAYS close the cylinder valve and, if required, seal with a plug, even if the cylinder is empty. Ask your propane retailer if a plug is required.
- NEVER keep a filled cylinder inside a hot vehicle or transport it inside a closed trunk.
- ALWAYS place the cylinder in a well-ventilated area of the vehicle.
- ALWAYS proceed directly to your destination and immediately remove the cylinder from your vehicle.
- The law places limits on the number of cylinders and the amount of propane that can be transported in closed-bodied vehicles such as passenger cars and vans. Ask your propane retailer for more information on state and local codes that apply to you.

